



## RW 14

### Chop Saw - RW14

Part No.	Sr.No	Description	Qty
3253. 1. 20	1	brush cap	2
3251. 1. 28	2	carbon brush	2
3224. 1. 38	3	screw	4
3231. 1. 41	4	spring washer	4
3232. 1. 01	5	flat washer	4
3260. 1. 27	6	motor housing	1
3501. 1. 04	7	locking bar	1
3310. 1. 43	8	locking spring	1
3820. 3. 28	9	stator/field Assly	1
3231. 1. 42	10	spring washer	2
3224. 1. 42	11	screw	2
3312. 1. 02	12	bearing sleeve	1
272. 1. 96	13	bearing 6000 2RS	1
3233. 1. 10	14	bearing washer	1
3830. 3. 28	15	Armature	1
272. 1. 43	16	bearing 6202 2RS	1
3326. 1. 06	17	fan	1

3344. 1. 08	18	fan guide	1
3501. 1. 05	19	fixed shaft	1
3501. 1. 06	20	stopper	1
3501. 1. 07	21	bearing lock	1
3224. 1. 43	22	screw	1
3241. 1. 08	23	nut	1
3604. 1. 29	24	bolt	1
3265. 1. 12	25	Gear box	1
272. 1. 96	26	bearing 6000 2RS	1
3300. 1. 04	27	big gear	1
3312. 1. 03	28	bearing cover	1
272. 1. 87	29	bearing 6204	1
3291. 1. 19	30	spindle	1
3409. 1. 09	31	flange	1
3340. 1. 11	32	grinding wheel	1
3409. 1. 10	33	flange	1
3236. 1. 01	34	washer	1
3604. 1. 30	35	bolt	1
3600. 1. 21	36	screw	6
3329. 1. 41	37	left handle	1
3330. 1. 33	38	switch	1
3329. 1. 42	39	right handle	1
3332. 1. 12	40	wheel guard	1
3600. 1. 22	41	screw	4
3279. 1. 23	42	spring clip	1
3232. 1. 02	43	flat washer	1
3360. 1. 27	44	handle sleeve	1
3329. 1. 43	45	handle	1
3501. 1. 08	46	rod	1
3501. 1. 09	47	pin	1
3501. 1. 10	48	fixed shaft	1
3232. 1. 03	49	flat washer	2
3332. 1. 13	50	spark guard	1
3232. 1. 04	51	flat washer	1
3241. 1. 09	52	nut	1
3224. 1. 44	53	screw	2
3231. 1. 43	54	spring washer	2
3230. 1. 05	55	flat washer	1
3331. 1. 02	56	vice jaw	1
3501. 1. 11	57	control rod	1
3501. 1. 12	58	holder	1
3231. 1. 44	59	spring washer	2
3600. 1. 23	60	screw	2

3501. 1. 13	61	pin	1
3600. 1. 24	62	screw	1
3230. 1. 06	63	flat washer	2
3332. 1. 14	64	guard	1
3310. 1. 44	65	spring	1
3600. 1. 25	66	screw	1
3241. 1. 10	67	nut	1
3313. 1. 06	68	base	1